

# TechLevel 100 Self-Leveling Underlayment

## 1 Product Name

TechLevel 100 Self-Leveling Underlayment

## 2 Manufacturer

Custom Building Products  
 Technical Services  
 10400 Pioneer Boulevard, Unit 3  
 Santa Fe Springs, CA 90670  
 Customer Support: 800-272-8786  
 Technical Services: 800-282-8786  
 Fax: 800- 200-7765  
 Email: contactus@cbpmail.net  
 custombuildingproducts.com  
 customtechflooring.com

## 3 Product Description

TechLevel™ 100 is a high quality self-leveling underlayment that achieves greater than 4000 psi compressive strength. TechLevel 100 levels floors prior to the installation of tile, resilient flooring, carpet, wood and other floor coverings. This underlayment can be applied up to 1.5" (3.8 cm) thick in one pour and seeks its own level in minutes.

### Key Features

- Levels floors from 3/16" to 1-1/2" thick
- Crack resistant
- Exceeds ASTM requirements for resilient floor covering installations

### Uses

#### Suitable as an Underlayment for:

- Carpet
- Wood, parquet
- Vinyl composition tile (VCT)
- Sheet vinyl flooring
- Laminated flooring
- Vitreous, semi-vitreous or non-vitreous tile
- Ceramic, mosaic, quarry or cement body tile
- Impervious porcelain and glass tile
- Brick and stone veneer
- Cement-based precast terrazzo
- Natural stone tile
- Stone, terrazzo

#### Suitable Substrates

- Absorbent concrete
- Non-absorbent concrete
- Lightweight concrete
- Gypsum-based underlayments
- Existing ceramic tile
- Cement terrazzo
- Epoxy terrazzo
- Exterior grade plywood
- OSB
- Cutback adhesive residue
- Resilient flooring
- Properly prepared steel and aluminum



### Composition of Product

TechLevel™ 100 is a proprietary dry blend of copolymers, cements, and inorganic chemicals.

### Benefits of Product in the Installation

- Can be applied from 3/16" to 1.5" (3.8 cm) thick in a single pour
- Cures fast and develops high early-strength for quick installation
- Crack resistant

### Limitations to the Product

- For interior use only. Do not use when temperature is below 50° F (10° C) or above 90° F (32° C).
- Do not bond directly to hardwood, Luan plywood, particle board, parquet, cushion or sponge-back vinyl flooring, metal, fiberglass or plastic. Contact technical services for recommendations.
- Do not use as a permanent wear surface.
- Do not use on sloped surfaces that require drainage.
- Precautions should be taken when applying over post-tensioned concrete, pre-stressed concrete or prefabricated concrete planks. Contact technical services for further details.

### Packaging

50 lb. (22.68 kg) Bag

## 4 Technical Data

### Applicable Standards

ASTM International (ASTM)

- ASTM C1708 Standard Test Methods for Self-leveling Mortars Containing Hydraulic Cements
- ASTM C627 Standard Test Method for Evaluating Ceramic Floor Tile Installation Systems Using the Robinson-Type Floor Tester
- ASTM F1869 Standard Test Method for Measuring Moisture Vapor
- ASTM F710 Standard Practice for Preparing Concrete Floors to Receive Resilient Flooring

Resilient Floor Covering Institute (RFCI) Recommended Work Practices for Removal of Resilient Floor Coverings

Tile Council of North America (TCNA) TCNA Handbook for Ceramic Tile Installation, TCNA Method EJ171

# TechLevel 100 Self-Leveling Underlayment

American National Standards Institute (ANSI) ANSI A108.01 and A108.02 of the American National Standards for the Installation of Ceramic Tile

## Technical Chart

| Property                              | Test Method | Typical Results    |
|---------------------------------------|-------------|--------------------|
| Pot Life                              |             | 15 minutes         |
| Flow Time                             |             | 18 minutes         |
| Compressive Strength at 28 days       | ASTM C-109  | >4,000 psi         |
| Flexural Strength at 28 days          | ASTM C-109  | >800 psi (5.5 MPa) |
| Walkable Hardness                     |             | 2 - 4 Hours        |
| Time Before Installing Floor Covering |             |                    |
| Ceramic tile                          |             | >4 Hours           |
| Most Floor Coverings                  |             | 30 Hours           |

## Environmental Consideration

Custom® Building Products is committed to environmental responsibility in both products produced and in manufacturing practices. Use of this product may contribute to LEED® certification.

## 5 Instructions

### General Surface Prep

**USE CHEMICAL-RESISTANT GLOVES, such as nitrile, when handling product.**

All surfaces must be structurally sound, clean, dry and free from contaminants that would prevent a good bond. Concrete must be fully cured. Refer to final flooring manufacturer's requirements for maximum moisture vapor transmission limitations. Concrete surfaces should be primed with an appropriate CustomTech™ primer. Smooth concrete surfaces, existing glazed tile, terrazzo, or polished stone must be roughened or scarified. Concrete surfaces must be mechanically profiled and prepared by shotblasting, sandblasting, water-jetting, scarifying, diamond-grinding or other engineered approved methods (reference ICRI CSP 3 standards for acceptable profile height).

### Bonding to Cement Surfaces

Contaminants or curing compounds should be mechanically removed before installation. Concrete must be free of efflorescence and not subject to moisture beyond the floor covering manufacturers' limits or hydrostatic pressure. Lightweight concrete surfaces must have a tensile strength in excess of 200 psi (1.4 n/mm<sup>2</sup>).

### Bonding to Plywood Surfaces

Plywood floors, including those under resilient flooring, must be structurally sound and must meet all industry guidelines. For questions about proper subfloor installation, call Custom Technical Services. A 2.5 lb/yd<sup>2</sup> metal lath must be fastened every 6" - 8" (15 - 20 cm) with fasteners that have a galvanized or corrosion-resistant coating over primed surfaces.

### OSB Underlayments

OSB underlayments should be coated with 10-15 mils of [RedGard® Waterproofing and Crack Prevention Membrane](#) prior to priming with an appropriate [CustomTech™ primer](#). A 2.5 lb/yd<sup>2</sup> metal lath must be fastened every 6" - 8" (15 - 20 cm) with fasteners that have a galvanized or corrosion-resistant coating. A minimum of 1/4" (6 mm) of TechLevel 100 can be applied over this properly prepared OSB.

### Bonding to Gypsum Surfaces

Gypsum-based underlayments must obtain a minimum 2000 psi (13.8 MP) compressive strength. The underlayment must be sufficiently dry and properly cured to the manufacturer's specifications for permanent, non-moisture permeable coverings. Surfaces must be structurally sound and subject to deflection not to exceed the current industry standards. Surfaces shall be free of all grease, oil, dirt, dust, curing compounds, waxes, sealers, efflorescence, or any other foreign matter.

All Gypsum surfaces should be primed with a properly applied sealer or a primer coat of [RedGard](#), consisting of 1 part RedGard diluted with 4 parts clean, cool water. Mix in a clean bucket at low speed to obtain a lump-free solution. The membrane can be brushed, rolled or sprayed to achieve an even coat. Apply the waterproofing coat to the floor at a rate of 300 sq. ft.l (7.5 sq. m/L). Drying time depends on site conditions, but is normally less than 1 hour. Extremely porous surfaces may require 2 coats. At this point, an appropriate [CustomTech™ primer](#) and TechLevel 100 can be applied to the primed lightweight or gypsum based surface. Refer to the individual product data sheet or packaging directions for application instructions. Expansion joints must be installed in accordance with local building codes and industry guidelines.

### Bonding to Cutback Adhesive

Adhesive layers must be removed. **Use extreme caution:** adhesives may contain asbestos fibers. Do not sand or grind adhesive residue, as harmful dust may result. Never use adhesive removers or solvents, as they soften the adhesive and may cause it to penetrate into the concrete. Adhesive residue must be wet-scraped to the finished surface of the concrete, leaving only the transparent staining from the glue. To determine desirable results, do a test bond area before starting. Refer to the RFCI Pamphlet "Recommended Work Practices for Removal of Resilient Floor Coverings" for further information.

### Priming

Prime all surfaces with an appropriate CustomTech™ primer before application of TechLevel 100.

### Joints or Cracks in Substrate

Expansion joints and cold joints, as described in ANSI A108.01, should be carried from the substrate up through the tile or flooring surface and filled with an appropriate elastomeric sealant, such as Custom's® 100% Silicone Caulk. For the proper treatment of control or saw cut joints and cracks for flooring, refer to ASTM F710. For tile installations, refer to TCNA Details EJ171, F125 & F125A. Contact Custom's® Technical Services for additional information.

### Mixing Ratios

Mix the entire 50 lb (22.68 kg) bag of powder with 5.25 - 5.75 quarts (5 - 5.4 L) of clean, cool water.

# TechLevel 100 Self-Leveling Underlayment

## Mixing Procedures

### Barrel:

Mix 50 lb. (22.68 kg) bag of powder with the appropriate amount of clean, cool water. Slowly add powder to water while mixing with a heavy-duty 1/2" (13 mm) electric drill and an "egg-beater" mixing paddle at minimum 650 RPM. Thoroughly mix for 2 minutes to a lump-free consistency. Do not overmix. Overmixing or moving the mixer up and down during the mixing process could trap air, which could shorten the pot life or cause pinholing during application and curing.

### Pumping:

TechLevel 100 can be pumped with a mixing pump. Adjust the water setting to obtain the optimum workability. Do NOT overwater. Pump the mix and use spreader to evenly distribute the materials to desired thickness.

## Application of Product

Apply an appropriate CustomTech™ primer according to the specifications in the respective technical data sheet for each product.

Pour or pump TechLevel 100, then spread with a long-handled gauged spreader. Will seek its own level during the first 20 minutes. For featheredging and touch-ups, use a smoothing tool. Can be applied up to 1.5" (3.8 cm) thick in one application. If a second layer is required, install immediately after the first layer has set to a walkable hardness. If the first layer has dried over 12 hours, re-prime before second application. Dries to a walkable hardness in 2 - 4 hours. For pumping and large scale applications, contact Custom's® Technical Services Department for more information.

## Curing of Product

Install non-moisture-sensitive ceramic tile or stone in 4 hours; all other floor coverings should be installed after 30 hours. Cure time can vary with temperature and humidity. Test for moisture content before applying vinyl or wood flooring to the surface of the self-leveler.

## Cleaning of equipment

Clean with water before material dries.

## Health Precautions

See Safety Data Sheet for complete safety information. This product contains Portland cement. Avoid eye contact or prolonged contact with skin. Wash thoroughly after handling. If eye contact occurs, flush with water for 15 minutes and consult a physician. Use with adequate ventilation; do not breathe dust and wear a NIOSH approved respirator. If ingested, do not induce vomiting; seek medical attention immediately.

## Conformance to Building Codes

Installation must comply with the requirements of all applicable local, state and federal code jurisdictions.

## 6 Availability & Cost

| LOCATION   | ITEM CODE | SIZE             | PACKAGE |
|------------|-----------|------------------|---------|
| USA/Canada | TL10050T  | 50 lb (22.68 kg) | Bag     |

## 7 Product Warranty

Obtain the applicable **LIMITED PRODUCT WARRANTY** at [www.customtechflooring.com/en-US/reference-library/warranties/](http://www.customtechflooring.com/en-US/reference-library/warranties/) or send a written request to Custom Building Products, Inc., Five Concourse Parkway, Atlanta, GA 30328, USA. Manufactured under the authority of Custom Building Products, Inc. © 2017 Quikrete International, Inc.

## 8 Product Maintenance

Properly installed product requires no special maintenance.

## 9 Technical Services Information

For technical assistance, contact Custom technical services at 800-272-8786 or [contact us online](#).

## 10 Filing System

Additional product information is available from the manufacturer upon request.

# TechLevel 100 Self-Leveling Underlayment

---

## Related Products

### Coverage

TYPICAL SQUARE FOOT COVERAGE PER 50 LB BAG (SQUARE METER PER 22.68 KG)

| Thickness      | Coverage (sq ft) |     | Coverage (sq m) |      |
|----------------|------------------|-----|-----------------|------|
|                | Min              | Max | Min             | Max  |
| 1/8" (3.2 mm)  | 46               | 48  | 4.3             | 4.5  |
| 3/16" (4.8 mm) | 31               | 32  | 2.8             | 2.9  |
| 1/4" (6.4 mm)  | 23               | 24  | 2.1             | 2.2  |
| 3/8" (9.5 mm)  | 15.3             | 16  | 1.4             | 1.5  |
| 1/2" (12.7 mm) | 11.5             | 12  | 1.07            | 1.1  |
| 3/4" (19 mm)   | 7.7              | 8   | 0.72            | 0.74 |
| 1" (25.4 mm)   | 5.7              | 6   | 0.53            | 0.56 |
| 1 1/2" (38 mm) | 3.8              | 4   | 0.35            | 0.37 |
| 2" (51 mm)     | 2.9              | 3   | 0.27            | 0.28 |

Chart for estimating purposes. Coverage may vary based on installation practices and jobsite conditions. For more sizes, use the material calculator at [CustomBuildingProducts.com](http://CustomBuildingProducts.com) or contact CUSTOM Technical Services at 800-282-8786.